



RELAY CAN BE MOUNTED IN THE MULTIPLEX PANEL

1. LOCATE THE INPUT CONNECTOR OF THE MULTIPLEX MODULE AND REMOVE WIRE # B1-104 PUTTING IT TO #85 ON THE BOSCH RELAY
2. LOCATE THE OUTPUT CONNECTOR OF THE MULTIPLEX MODULE AND REMOVE WIRE #B2-109 PUTTING IT TO #87 ON THE BOSCH RELAY
3. LOCATE THE CHASSIS POWER STUD IN THE PANEL AND INSTALL A 14 GA WIRE FROM IT TO #86 ON THE BOSCH RELAY INSTALLING EITHER A 10 AMP FUSE OR CIRCUIT BREAKER IN LINE. INSTALL A JUMPER FROM WIRE BETWEEN THE FUSE/BREAKER TO #30 ON THE BOSCH RELAY

BOSCH RELAY  
# 1077718

Title: HORN REWIRE FOR VISION

JOHN JOHNSTON

Created With a Trial Copy of SmartDraw

To remove this watermark please purchase a copy