



1. Install 20 A fuse with constant power and flasher in Power Distribution Unit.
2. Run 10 gauge RED wire from load side of flasher to the PDU.
3. Install relays in lower left side of PDU.

Wires B3-107 and B3-108 are in the lower right side plug of the MPX Module.  
Wires B1-005 and B1-007 are in the left side plug of the MPX Module.