



BLUE BIRD

**2010**

**D3FE**

**SERVICE MANUAL**

*APPLIES TO THESE MODELS*

**ALL AMERICAN FORWARD ENGINE**

**TX3 FORWARD ENGINE**

**GLOBAL TRANSIT FORWARD ENGINE**

# VOLUME

1

*Introduction*

*Chassis Frame*

*Front Axle & Suspension*

*Rear Axle & Suspension*

*Air Brakes*

*Hydraulic Brakes*



BLUE BIRD

**2010**

**D3FE**

**SERVICE MANUAL**

*APPLIES TO THESE MODELS*

**ALL AMERICAN** FORWARD ENGINE

**TX3** FORWARD ENGINE

**GLOBAL TRANSIT** FORWARD ENGINE



BLUE BIRD

**D3FE**



10008283

© 2009 Blue Bird Corporation. All rights reserved.

The Blue Bird All American complies with all applicable federal and state regulations. These include, but are not limited to, Federal ADA as well as state accessibility, safety and security requirements.

The Blue Bird All American meets all applicable Federal Motor Vehicle Safety Standards (FMVSS) rules and regulations.

In the event of any conflict between the requirements of this publication and any applicable legal requirement, the legal requirement prevails. Technical requirements that exceed the legal requirements are not considered to conflict.

Many of the components of Blue Bird buses are obtained from outside suppliers. Where maintenance and/or service information conflicts with the component manufacturers documentation, the manufactures's documentation prevails.

Blue Bird Corporation continually endeavors to improve its product and reserves the right to change without notice. The material presented in this manual is accurate at the time of publication.



<b>Introduction / 15</b>	<b>15</b>
Blue Bird Strength; Blue Bird Innovation / 15	
Backed By Blue Bird / 15	
Reporting Safety Defects / 17	<b>23</b>
About This Manual / 18	
About the TechReference CD / 20	<b>35</b>
<b>Chassis Frame / 23</b>	<b>155</b>
Chassis Frame Overview / 23	
Frame Maintenance Overview / 23	
Huck Fasteners / 24	
Body Tie-down Clamps and Angles / 25	
Swing-Out Radiator / 26	
Rubber Mounting Pads / 26	
<b>Front Axle &amp; Suspension / 35</b>	
Overview / 35	
Maintenance / 35	
Airtek / Softek Suspension: Appendix 1 / 41	
<b>Rear Axle &amp; Suspension / 155</b>	
Overview / 155	
Maintenance / 156	
Rear Spring & Axle Removal / 159	
Rear Spring & Axle Installation / 161	
Rear Air Suspension / 164	
Comfort Air Suspension: Appendix 1 / 167	



<b>Air Brakes / 205</b>	
Overview / 205	
Automatic Traction Control / 209	
Brake Interlock / 213	
Maintenance Overview / 214	
Air Compressor / 215	
Air Compressor Governor (D-2) / 216	
Air Dryer (Optional) / 218	
Air Tanks / 221	
Treadle Valve (E-8P) / 223	
Relay Valve (R-12) / 225	
Park Brake Control Valve (PP-DC) / 227	
ABS Modulator Valves (M-32QR) / 228	
ABS Wheel Speed Sensors (WS-24) / 230	
ABS Controller (EC-60) / 232	
Brake Chambers, Front / 233	
Brake Chambers, Rear / 235	
Slack Adjusters / 239	
Brake Shoes & Drums / 244	
Front Brake Assembly / 246	
Rear Brake Assembly / 248	
AD-9 Air Dryer: Appendix 1 / 251	
PP-DC Park Control Valve: Appendix 2 / 275	
SR-7 Spring Brake Valve: Appendix 3 / 281	
EC-60 ABS / ATC Controllers: Appendix 4 / 289	
Cam Brakes & Automatic Slack Adjusters: Appendix 5 / 333	

205

389

<b>Hydraulic Brakes / 389</b>	
Overview / 389	
Maintenance Overview / 390	
Master Cylinder / 395	
Booster / 397	
ABS Modulator / 400	
Wheel Speed Sensors / 402	
ABS Electronic Control Unit (ECU) / 404	
Calipers / 407	
Brake Pads / 408	
Brake Rotors / 409	
Brake Rotor Removal / 409	
Front Brake Reassembly / 410	
Rear Brake Removal, / 412	
Rear Brake Rotor Reassembly / 414	
Brake Interlock, Hydraulic / 420	
Hydraulic Brake Booster & Master Cylinder: Appendix 1 / 427	
Hydraulic Anti-Lock Braking System: Appendix 2 / 455	
Four-Piston Quadrauclic Disc Brake Caliper: Appendix 3 / 491	
Brake Interlock System: Appendix 4 / 517	



<b>Power Drivetrain / 539</b>		
Overview / 539		
Engine Access / 540		
Transmission / 542		
Transmission Maintenance / 544		
Shift Cable Adjustment / 546		
Drive Line / 547		
Transmission Service Prognostics / 550		
<b>Cooling / 553</b>		
Overview / 553		
About Coolant / 560		
Standard Equipment Coolant / 560		
Optional Extended Life Coolant / 560		
Coolant Decals / 560		
Coolant Maintenance / 561		
Radiator Shutters / 563		
Radiator / 566		
Cooling System Drain, Flush & Refill / 568		
Fan Clutch / 572		
<b>Intake &amp; Exhaust / 573</b>		
Intake Overview / 573		
Intake System Maintenance / 575		
Exhaust System / 578		
Regeneration Process In Cummins Engines / 579		
DPF Regeneration In Blue Bird Buses / 582		
Levels of Notification / 583		
Stationary Regeneration Precautions / 586		
Exhaust Piping / 588		
<b>Fuel System / 595</b>		
Fuel System / 595		
Accelerator Control, Electronic / 600		
Throttle Position Sensor / 600		
Auto Calibration / 601		
Accelerator Testing And Troubleshooting / 602		
<b>Instrumentation / 603</b>		
Overview / 603		
Instrument Cluster Removal / 605		
Testing a Gauge By Substitution / 605		
Instrument Cluster: Appendix 1 / 607		

539

553

573

595

603



**Body Electrical / 677**

- Overview / 677
- Body Control Module (BCM) / 678
- Ladder Logic Lines / 681
- Troubleshooting Body Electrical Circuits / 685
- Body Wiring Schematics / 686
- BCM Ladder Logic Diagrams / 687
- Doran Warning Light Monitor / 691
- Doran Troubleshooting / 691
- Heat and Air Control Panels / 692
- Left Switch Panel / 694
- Right Switch Panel / 696

**Chassis Electrical / 699**

- Charging System / 699
- Alternator Removal / 703
- Automatic Belt Tensioner / 704
- Starter / 705
- Starter Motor Removal / 711
- J-1939 Harness Diagnostics / 712
- Chassis Wiring Schematics / 713

**Steering / 765**

- Overview / 765
- Steering System Operation / 766
- Steering System Maintenance / 767
- Steering Column & Steering Wheel / 768
- Steering Gear / 770
- Steering Pump / 771
- Flushing the Steering System: Appendix 1 / 775
- Air Bleeding the Steering System: Appendix 2 / 777
- THP / PCF Steering Gear: Appendix 3 / 779
- Steering Diagnostics: Appendix 4 / 845
- TAS Poppets: Appendix 5 / 897

677

699

765





**Body Structure / 909**

- Overview / 909
- Body Glass / 909
- Windshield Glass Replacement / 909
- Rear Vision Glass Replacement / 911
- Split Sash Window and Glass Replacement / 912
- Rear Vision Glass Replacement / 913
- Transit Sliding Window Removal / 914
- Transit Window Glass Replacement / 914
- Outward Opening Entrance Door / 916
- Manual Door Control / 918
- Pneumatic Door Opener / 919
- Electric Door Opener / 920
- Door Panels / 921
- Stop Arms / 924
- Auto Glass Replacement: Appendix 1 / 925

**Body Interior / 983**

- Overview / 983
- Driver's Seat / 983
- Deluxe Driver's Seat / 984
- Seat Care and Cleaning Tips / 985
- Passenger DOT Seats / 985
- Track Mounted Passenger Seats / 987
- Seat Belts & Shoulder Harnesses / 987

**Body Finish / 991**

- Exterior Paint / 991
- Interior Paint / 991
- Front End / 991
- Rear End / 992
- Headlining / 992
- Fastening / 992
- Floor Covering / 992
- Undercoating / 993
- Lettering/Decals / 993

909

983

991



- Specs & Maintenance / 995**
- General Specification, Chassis / 995
- General Specification, Body / 1000
  - Dimensions / 1006
  - Fastener Grades / 1007
  - Service Precautions / 1010
  - Jacking and Towing / 1012
  - Fluids & Filters / 1015
- General Maintenance Schedules / 1017
- Maintenance Task Schedule / 1018

- Index / 1033**

995

1033



# Volume 2

## Power Drivetrain / 539

- Overview / 539
- Engine Access / 540
- Transmission / 542
- Transmission Maintenance / 544
- Shift Cable Adjustment / 546
- Drive Line / 547
- Transmission Service Prognostics / 550

## Cooling / 553

- Overview / 553
- About Coolant / 560
- Standard Equipment Coolant / 560
- Optional Extended Life Coolant / 560
- Coolant Decals / 560
- Coolant Maintenance / 561
- Radiator Shutters / 563
- Radiator / 566
- Cooling System Drain, Flush & Refill / 568
- Fan Clutch / 572

## Intake & Exhaust / 573

- Intake Overview / 573
- Intake System Maintenance / 575
- Exhaust System / 578
- Regeneration Process In Cummins Engines / 579
- DPF Regeneration In Blue Bird Buses / 582
- Levels of Notification / 583
- Stationary Regeneration Precautions / 586
- Exhaust Piping / 588

## Fuel System / 595

- Fuel System / 595
- Accelerator Control, Electronic / 600
- Throttle Position Sensor / 600
- Auto Calibration / 601
- Accelerator Testing And Troubleshooting / 602

## Instrumentation / 603

- Overview / 603
- Instrument Cluster Removal / 605
- Testing a Gauge By Substitution / 605
- Instrument Cluster: Appendix 1 / 607

539

553

573

595

603





**Body Electrical / 677**

- Overview / 677
- Body Control Module (BCM) / 678
- Ladder Logic Lines / 681
- Troubleshooting Body Electrical Circuits / 685
- Body Wiring Schematics / 686
- BCM Ladder Logic Diagrams / 687
- Doran Warning Light Monitor / 691
- Doran Troubleshooting / 691
- Heat and Air Control Panels / 692
- Left Switch Panel / 694
- Right Switch Panel / 696

**Chassis Electrical / 699**

- Charging System / 699
- Alternator Removal / 703
- Automatic Belt Tensioner / 704
- Starter / 705
- Starter Motor Removal / 711
- J-1939 Harness Diagnostics / 712
- Chassis Wiring Schematics / 713

**Steering / 765**

- Overview / 765
- Steering System Operation / 766
- Steering System Maintenance / 767
- Steering Column & Steering Wheel / 768
- Steering Gear / 770
- Steering Pump / 771
- Flushing the Steering System: Appendix 1 / 775
- Air Bleeding the Steering System: Appendix 2 / 777
- THP / PCF Steering Gear: Appendix 3 / 779
- Steering Diagnostics: Appendix 4 / 845
- TAS Poppets: Appendix 5 / 897

677

699

765



**Body Structure / 909**

- Overview / 909
- Body Glass / 909
- Windshield Glass Replacement / 909
- Rear Vision Glass Replacement / 911
- Split Sash Window and Glass Replacement / 912
- Rear Vision Glass Replacement / 913
- Transit Sliding Window Removal / 914
- Transit Window Glass Replacement / 914
- Outward Opening Entrance Door / 916
- Manual Door Control / 918
- Pneumatic Door Opener / 919
- Electric Door Opener / 920
- Door Panels / 921
- Stop Arms / 924
- Auto Glass Replacement: Appendix 1 / 925

**Body Interior / 983**

- Overview / 983
- Driver's Seat / 983
- Deluxe Driver's Seat / 984
- Seat Care and Cleaning Tips / 985
- Passenger DOT Seats / 985
- Track Mounted Passenger Seats / 987
- Seat Belts & Shoulder Harnesses / 987

**Body Finish / 991**

- Exterior Paint / 991
- Interior Paint / 991
- Front End / 991
- Rear End / 992
- Headlining / 992
- Fastening / 992
- Floor Covering / 992
- Undercoating / 993
- Lettering/Decals / 993

909

983

991



- Specs & Maintenance / 995**
- General Specification, Chassis / 995
- General Specification, Body / 1000
  - Dimensions / 1006
  - Fastener Grades / 1007
  - Service Precautions / 1010
  - Jacking and Towing / 1012
  - Fluids & Filters / 1015
- General Maintenance Schedules / 1017
- Maintenance Task Schedule / 1018

- Index / 1033**

995

1033