



**BLUE BIRD**

March 03, 2011

**SERVICE MEMORANDUM  
NO. SM1103**

**MEMO TO:** All Blue Bird Dealers

**SUBJECT:** Ricon and Braun Wheelchair Lift Mounting Bolts

**MODEL YEAR:** 2011

**MODELS AFFECTED:** A3FE, A3RE, BBCV, D3FE & D3RE

Blue Bird installed lifts by Ricon or Braun only require (8) mounting fasteners thru the base mounting plate to the floor. The lift base mounting plates contain (10) mounting holes, the (2) holes located in the center of the base mounting plate are not used and do not require fasteners.

Sincerely,

Bill Coleman  
Blue Bird Engineering Services  
[bill.coleman@blue-bird.com](mailto:bill.coleman@blue-bird.com)  
478-822-2242